

# MWW LED INSTALLATION AND ASSEMBLY INSTRUCTIONS



SMARTVISION®

**CAUTION:** Risk of shock. Disconnect power before installing or servicing.

**WARNING:** Before proceeding, read all instructions carefully to insure proper and safe installation.

**WARNING:** Risk of electrical shock. High temperatures inside luminaire. Make certain line voltage corresponds with ballast/driver primary voltage (see ballast/driver label).

**WARNING:** All wiring to be performed per National Electrical Code and local code by a qualified electrician.

**IMPORTANT:** Not every unit is identical. Placement of proper luminaire is important. Refer to layout drawing to verify location identification, product location, and feed points.

**IMPORTANT:** Do not electrically connect to live wiring.




Installation Questions?  
Call LSI Field Service Department at:  
1-800-436-7800 Ext. 3300 Fax 877-861-1368

LSI Industries Inc. ♦ 10000 Alliance Road ♦ Cincinnati, OH 45242 ♦ 513-793-3200 ♦ Fax (513) 793-0147 ♦ [www.lsi-industries.com](http://www.lsi-industries.com)

# MWW LED INSTALLATION AND ASSEMBLY INSTRUCTIONS



SMARTVISION®



**NOTE: Remove the LED panel to gain access to the driver for servicing.**



Installation Questions?  
Call LSI Field Service Department at:  
1-800-436-7800 Ext. 3300 Fax 877-861-1368

