# **Installation and Assembly Instructions Opulence Wall Mount (OPS) Series**



### /!\ WARNING

#### Risk of fire, electric shock, injury or property damage

Risk of electric shock--Disconnect power to equipment before installing or servicing.

This equipment must be installed according to all applicable codes & ordinances.

Installation and service of this equipment must be performed by qualified service personnel.

Do not install damaged equipment.

Read theses instructions before installing, servicing or maintaining this equipment.

Save these instructions for maintaining and servicing.

Use of the Wall Mount Accesory Bracket is suitable for interior wall surfaces and/or covered Damp Locations only. The Wall Mount Accessory Bracket is not suitable for Wet Locations.

## **!** CAUTION

Failure to follow instructions or altering equipment could result in damage and void warranty.

Edges may cut--wear gloves while handling or servicing this equipment.

Inspect equipment for damage from shipping and handling.

#### **LUMINAIRE PREPARATION**

1. Remove the luminaire from the carton and inspect luminaire for damage. Do not install a damaged luminaire.


#### WIRING INFORMATION


**Red Wire** is for Battery Back-Up option. Connect to 120-277V un-switched power source otherwise cap off wire if option wasn't ordered.


Installation Questions

Call LSI Field Service Dept.

800-436-7800 ext. 3300









## LSI Industries Inc. 10000 Alliance Rd. Cincinnati, OH 45242 www.lsi-industries.com 764916 Rev. 06/01/21

## **Installation and Assembly Instructions Opulence Wall Mount (OPS) Series**

- 1. Remove the J-Box Bracket from the luminaire by loosening the (2) Set Screws, Fig. 1.
- 2. Using (2) fasteners (8-32 screws) by others, attach J-Box Bracket to J-Box.
- 3. Make wiring connections and position wire nut branch connections inside junction box.
- 4. Re-position Luminaire on J-Box Bracket and tighten Set Screws, Fig. 2.



J-Box Bracket



Installation Questions Call LSI Field Service Dept. 800-436-7800 ext. 3300

LSI Industries Inc. 10000 Alliance Rd. Cincinnati, OH 45242 www.lsi-industries.com 764916 Rev. 06/01/21